


Measuring Trigger Efficiency

- Important component of cross section measurement: it is NOT in general 1.0!
- Need to measure this from data because trigger hardware is not emulated perfectly in software
- We will see this depends on the analysis in question (by my definition)

Three-level trigger schematic




Trigger towers / Regions of Interest

- LVL1 uses trigger towers of size 0.1×0.1
 - Combines multiple EM cal towers
 - Passes a RoI to the LVL2 algorithms with similar resolution
- LVL2 uses fine segmentation 0.025×0.0245
 - Shower shape calculations
 - Tracking information
- See also ATL-DAQ-2000-002 “Selection of high- p_T electromagnetic clusters by the level-2 trigger of ATLAS,” by Saul Gonzalez et al.

Specific LVL1 shower criteria

- Electron E_T in 1x2 trigger tower > 25 GeV
- Electromagnetic ring isolation (in 12 towers around 2x2 core) < 3 GeV
- Hadronic core leakage (in 2x2 towers behind EM cal) < 2 GeV
- Hadronic ring isolation (in 12 towers around 2x2 core) < 2 GeV



Specific LVL2 shower criteria

- Hadronic leakage: EM showers deposit little energy in the Had Cal. 2.5% or less
- Lateral shower shape 3x7 compared to 7x7: ratio >0.90
- Lateral width: variance of the 3x5 cell block
- Energy difference between two maxima in first ecal sample: this gets rid of jets with π^0 decays
 - energy in second maximum
- Total shower width relative to first energy maximum

Trigger Efficiency Definition

- Measured with respect to offline reconstruction. Why?
- $N = \sigma \times \varepsilon_{\text{trig}} \times \varepsilon_{\text{reco}} \times L$
- So L1 eff = $N(\text{pass L1}) / N(\text{reco})$
- L2 eff = $N(\text{pass L1} \ \&\& \ \text{pass L2}) / N(\text{reco})$
- There is at least one alternative to this definition...

Ensuring Real Electrons

- Electrons in inclusive stream come from W/Z production but **also include fakes!**
- Trigger efficiency measurement requires a reliable source of clean electrons. Why?
 - *Note that any “electron” would do as long as its shower shape and isolation characteristics are same as for true electrons -- this is unlikely*
- Tight electron requirements and Z mass selection ensure we are dealing with true electrons

Trigger Hypothesis

- Trigger algorithm which checks for a certain signature: e , γ , jet
- TrigT1EMHypo, TrigL2CaloHypo, TrigL2IDCaloHypo, TrigEFEgammaHypo
 - L1 (calo-based): calo energy, isolation
 - L2 (calo): shower shape, energy isolation in cone
 - L2 (track): match to L2 ID track
 - EF: nearly the same as offline requirements

Global Trigger Decision

- After rerunning the trigger hypotheses, trigger decision is in StoreGate under key “MyTriggerDecision” (or “MyTriggerDecision+”)

```
// find summary trigger decision
const TriggerDecision* trigDec = 0;
StatusCode sc=m_storeGate->retrieve( trigDec,
                                     "MyTriggerDecision" );
if( sc.isFailure() || !trigDec ) {
    mLog << MSG::WARNING
        << "No TriggerDecision found in TDS"
        << endreq;
    return StatusCode::FAILURE;
}
```

Parsing the Trigger Decision

- Trigger decision is packed into a word which needs to be parsed
 - Check that your trigger is defined in the current table
 - Then check that the event passes the trigger
 - Otherwise snap out of the event

```
// check trigger status before continuing
if ( ! (trigDec->isDefined("L2_e25i", 2)
      && trigDec->isTriggered("L2_e25i")) )
    return StatusCode::SUCCESS;
```

Will be interesting to compare this with the EventHeader bits

Trigger Objects

- L1EMTauObject
 - HdCore, EmCore, HdIsol, EmIsol
- TriggerElectron (L2)
 - Links to associated cluster and track

Retrieving Trigger Objects

```
for (l1EmObjectItr = l1EmContainer->begin();
    l1EmObjectItr < l1EmObjectItrE;
    l1EmObjectItr++) {
    mLog << MSG::DEBUG
        << "EmCore / Eta values for this L1 EM trigger object are "
        << (*l1EmObjectItr)->L1EM_EmCore() << " / "
        << (*l1EmObjectItr)->L1EM_eta() << endreq;
}
```

“Tag and Probe” Method

- Trigger on one electron (“tag”) and measure efficiency to trigger on the second electron (“probe”). Why not use just one electron?
 - Biased trigger efficiency (you need at least one trigger electron!)
- Alternative is to use backup (calibration) trigger paths which pass events through without biasing selection

Trigger Efficiency Derivation

Based on counting number of events, not electrons!
Specify number of single-trigger object (M. Flowerdew)

Case A: electrons in different bins $\epsilon = N_2/N_1$

Case B: electrons in the same bin $\epsilon = 2N_2/(N_1 + N_2)$

Total efficiency is then:

$$\epsilon = \frac{N_2^A + 2N_2^B}{N_1^A + N_1^B + N_2^B} = \frac{N_2^A + 2N_2^B}{N_T}$$

Analysis Strategy

- Select events on e25i trigger
- Find good Z candidates using 2 electrons of opposite charge and reasonable mass cut
- Match reconstructed electrons to Level 2 trigger objects
- Check if matched trigger objects satisfy the trigger requirements
- Calculate efficiency as function of E_T , η , ϕ

Expect something like 97% at L1, 95% at L2, 94% at EF